

Micrometer Adjust Installed



Drill two holes in the chassis assembly to accommodate the bracket. The micrometer assembly mounting screws include nuts, so you can drill 0.221 through and use the nuts, or drill and tap 10-32.

The assembly attaches to the ZipLoader frame with a tee-nut that is tightened by a cam. Use 6mm hex wrench to tighten. Locate the assembly about 5.82 inches from the end, but do not tighten until the adjustment screw is mounted to the bracket to insure alignment.

