



OmniTurn Connectors (Amp CPC)

14 pin




Connector on cabinet
(Female sockets toward you)

14 pin




Connector on cable
(Male pins toward you)

14 pin




Connector on cable
(Male pins AWAY from you)

16 pin




Connector on cabinet
(MALE PINS toward you)

16 pin




Connector on cabinet
(Male pins AWAY from you)

16 pin




Connector on cable
(FEMALE SOCKETS toward you)


OmniTurn Connectors (DB9 & DB25)




DB9(M) FRONT



DB9(F) FRONT



DB25(M) FRONT VIEW



DB25(F) FRONT VIEW